

PROGRAMMING GUIDE FOR WIRELESS UNITS ON HYOSUNG

(FLIP OVER FOR GENMEGA/HANTLE/TRANAX MACHINES)

For TCP/IP Connection via Cat5 Cable

Verify Cat5 Cable is securely connected between ATM and Wireless Unit

Log into Operator Function screen using **Master Password**

Enter **Customer Setup > Select Processor > TCP/IP Type**

Columbus Data	STANDARD TCP/IP
Switch Commerce	VISA FRAMED TCP/IP
DNS	STANDARD TCP/IP
EFX	STANDARD OR VISA FRAMED TCP/IP
1 st ISO (ELAN)	CONTACT 1ST ISO/ELAN
PAI	STANDARD TCP/IP
Universal Money	CONTACT UM/ISO

****YOU MUST ENABLE SSL****

****SSL VERSION: TLS 1.2 OR ABOVE****

FOR SSL CERT ENABLE/DISABLE: *YOU MUST REACH OUT TO YOUR PROCESSOR*

Go back to **System Setup > Terminal IP > Disable DHCP**

Terminal IP Address	192.168.1.91 (RMS Users = 192.168.1.100)
Subnet Mask	255.255.255.0
Gateway	192.168.1.90
DNS	8.8.8.8 and 8.8.4.4

Go back to **Host Setup > Host Address > Enable URL**

Host Address #1 and #2: **See Below**

Host Ports #1 and #2: **(see Ports column below)**

<u>Processor</u>	<u>Host IP #1</u>	<u>Host IP #2</u>	<u>Ports</u>
Columbus Data	atm.columbusdata.net	atm.columbusdata.net	6965
Switch Commerce	atm1.switchcommerce.net	atm2.switchcommerce.net	1440
DNS	atmssl.dnsatm.com	atmtls.dnsatm.com	8008 or 8002
EFX	emv.sibisystems.com	emv.sibisystems.com	9056 or 9057
1 st ISO (ELAN)	CONTACT 1ST ISO/ELAN	CONTACT 1ST ISO/ELAN	
PAI	eftdebitatm.fnfis.com	eftdebitatm.fnfis.com	443
Universal Money	CONTACT UM/ISO	CONTACT UM/ISO	

PROGRAMMING GUIDE FOR WIRELESS UNITS ON GENMEGA/HANTLE/TRANAX

(FLIP OVER FOR HYOSUNG MACHINES)

For TCP/IP Connection via Cat5 Cable

Verify Cat5 Cable is securely connected between ATM and Wireless Unit

Log into Operator Function screen using **Master Password**

Enter **Customer Setup > Change Processor > Communication**

Columbus Data	SSL PASSTHROUGH, TLS 1.2 or above
Switch Commerce	SSL PASSTHROUGH, TLS 1.2 or above
DNS	SSL PASSTHROUGH, TLS 1.2 or above
EFX	SSL PASSTHROUGH, TLS 1.2 or above
1 st ISO (ELAN)	CONTACT 1ST ISO/ELAN
PAI	SSL PASSTHROUGH with ETX, TLS 1.2 or above
Universal Money	CONTACT UM/ISO

Go back to **System Setup > Device Setup > ATM TCP/IP Setup > TCP/IP Mode: Static**

Terminal IP Address	192.168.1.91 (RMS Users = 192.168.1.100)
Subnet Mask	255.255.255.0
Gateway	192.168.1.90
DNS	8.8.8.8 and 8.8.4.4

****YOU MUST HIT APPLY****

Go back to **Host Setup > Host IP Address**

Host Address #1 and #2: **See Below**

Host Ports #1 and #2: **(see Ports column below)**

<u>Processor</u>	<u>Host IP #1</u>	<u>Host IP #2</u>	<u>Ports</u>
Columbus Data	atm.columbusdata.net	atm.columbusdata.net	6965
Switch Commerce	atm1.switchcommerce.net	atm2.switchcommerce.net	1440
DNS	atmssl.dnsatm.com	atmtls.dnsatm.com	8008
EFX	emv.sibisystems.com	emv.sibisystems.com	9056 or 9057
1 st ISO (ELAN)	CONTACT 1ST ISO/ELAN	CONTACT 1ST ISO/ELAN	
PAI	eftdebitatm.fnfis.com	eftdebitatm.fnfis.com	443
Universal Money	CONTACT UM/ISO	CONTACT UM/ISO	